

USER GUIDE: Canyon Solar Motion Sensor Portable Light

SETUP

- Before first use, charge in direct sunlight for 6-8 hours.
- Choose location that receives direct sunlight during the day for optimal performance.

MAINTENANCE

- Remove light before driving.
- Do not submerge in water.
- Avoid spraying high-pressure water directly on light or solar panel.
- Do not clean with harsh chemicals.

TROUBLESHOOTING:

If light does not turn on, charge in direct sunlight for at least 30 mins.

LIGHT MODES

Press the button on the backside of the light to toggle through modes. (No remote required.)

1

Motion Sensor Light Mode

Light remains off when no motion is detected. Turns on at high brightness for 15 seconds when motion is detected, then turns off again.

2

Permanent On Mode

Light turns on automatically and stays at 10% brightness for up to 8 hours.

3

Smart Brightness Control Mode

Light stays at low brightness. Switches to high brightness for 15 seconds when motion is detected, then returns to low brightness.